

---

## Table of Contents

Demonstration of some basic matlab commands and .....	1
Construct filename, get image information .....	1
Read and display image .....	2
You can also read from a website: .....	3
Different image types and their operations .....	4
displays .....	5
Crop, : and end .....	7
Logical images and operations .....	8

## Demonstration of some basic matlab commands and

image processing tools

startup

```
cd TNM087-2015\Matlab\
```

```
impath = fullfile('C:', 'svn-enzo', 'TNM087-2015', 'Labs', 'Images');
```

07-Nov-2015 09:15:39

## Construct filename, get image information

```
imname = 'scarves_camerawhite.jpg'
```

```
imfile = fullfile(impath, imname)
```

```
imfjpg = imfinfo(imfile)
```

```
imname =
```

```
scarves_camerawhite.jpg
```

```
imfile =
```

```
C:\svn-enzo\TNM087-2015\Labs\Images\scarves_camerawhite.jpg
```

```
imfjpg =
```

```
Filename: 'C:\svn-enzo\TNM087-2015\Labs\Images  
\scarves_camerawh...
```

```
FileModDate: '27-Aug-2015 13:56:00'
```

```
FileSize: 2716366
```

```
Format: 'jpg'
```

```
FormatVersion: ''
```

```
Width: 5796
```

```
Height: 3870
```

```
BitDepth: 24
```

---

```
        ColorType: 'truecolor'
FormatSignature: ''
NumberOfSamples: 3
        CodingMethod: 'Huffman'
CodingProcess: 'Sequential'
        Comment: {}
```

## Read and display image

```
cimname = 'scarves.CR2'
cimfile = fullfile(impath,cimname);
infc2 = imfinfo(cimfile);

oimage = imread(fullfile(impath,imname));
figure(1)
subplot(1,2,1),imshow(oimage)
gim = rgb2gray(oimage);
subplot(1,2,2),imshow(gim)
figure(10)
imshowpair(oimage,gim,'montage')
whos
```

```
cimname =
```

```
scarves.CR2
```

Name	Size	Bytes	Class
Attributes			
ComputerAlias	1x2	4	char
ComputerName	1x11	22	char
DropBoxPath	1x24	48	char
MyBoxLiuPath	1x25	50	char
SVNPath	1x11	22	char
cimfile	1x47	94	char
cimname	1x11	22	char
gim	3870x5796	22430520	uint8
imfile	1x59	118	char
imfjpg	1x1	2720	struct
imname	1x23	46	char

---

<i>impath</i>	<i>1x35</i>	<i>70</i>	<i>char</i>
<i>infc_r2</i>	<i>4x1</i>	<i>597848</i>	<i>struct</i>
<i>knownmachines</i>	<i>1x4</i>	<i>528</i>	<i>cell</i>
<i>oimage</i>	<i>3870x5796x3</i>	<i>67291560</i>	<i>uint8</i>



**You can also read from a website:**

```
czim = imread('http://www.completedigitalphotography.com/CDP8/  
Chapter16/scarves.cr2');
```

---

```
figure(2)
imshow(czim)
```



```
close all
```

## Different image types and their operations

```
il6im = uint16(gim);
x=il6im(:);
fim = im2double(oimage);
disp([max(gim(:)),max(x),max(fim(:));...
      max(gim(:)+gim(:)),max(x+x),max(fim(:)+fim(:))])
disp([double(max(gim(:))),double(max(x)),double(max(fim(:))];...
      double(max(gim(:)+gim(:))),double(max(x
+x)),double(max(fim(:)+fim(:))])
doubleim = double(oimage);
disp([max(fim(:)),max(oimage(:)),max(doubleim(:))])
```

```
255  255    1
255  255    2
```

```
255   255    1
255   510    2
```

```
1  255  255
```

---


# displays

```
close all


figure(2)
imshow(il6im);
figure(3)
imshow(il6im,[])
figure(4)
imagesc(double(il6im)/double(max(il6im(:))))
figure(5)
imagesc(double(il6im)/double(max(il6im(:))))
colormap gray
axis image
axis off
axis tight

[sx,sy] = size(gim);
disp([imfjpg.Width,imfjpg.Height,sx,sy])

5796          3870          3870          5796
```









## Crop, : and end

```
cropim = gim(:,1000:end);  
size(cropim)  
figure(6)  
imshow(cropim)
```

```
ans =
```

```
3870      4797
```



## Logical images and operations

```
smallim = gim(1:4:end,1:4:end);  
darkim = smallim>128;  
truim = smallim;  
truim(darkim) = 128;  
figure(7)  
imshowpair(smallim,truim,'montage')  
figure(8)  
imshowpair(smallim,truim)
```







*Published with MATLAB® R2015b*